

Sound Card Notes

Power:

Because of the power requirements of the Sound Card there is a need for a larger power supply to power the system 9VDC @ 1000 mA.

If the Ztar will not run from the supply that we shipped to you, you can power the instrument from a USB 2.0 port on your computer, which will power just the Ztar but not the Sound card.

Connections:

The Ztar Sound card installation provides a ¼" Stereo Line Out jack and a 1/8" Stereo headphone jack

If you're using the Yamaha DB50XG soundcard please refer to the DB50XG manual for the Bank and Patch numbers to select the sounds you want. You can download the manual from the following link,

http://www.usersmanualguide.com/yamaha_audio/computer_peripheral_devices/db50xg