

Z7S Rear Panel



Power Connections:

The Z7S can be powered by either

- A) “phantom” power through the MIDI Output cable or
- B) USB from a host computer.

To connect to a MIDI system, attach a MIDI cable [make sure the cable has all five wires connected from end-to-end] from the MIDI Out port on the Z7S to the “Controller” port on the PB-1 Phantom Power Adapter. Press the power switch in the MIDI direction to power up.

To connect to a USB system, attach a standard USB A/B cable from the USB port on the Z7S to the USB port on your host computer. Flip the power switch in the USB direction to power up.

String Trigger Gain Adjustments:

You may adjust the gain for each of the String Triggers to achieve a response that is best suited to your playing style. A single-turn trimpot is provided inside the Z7S for each String Trigger which may be accessed through the adjustment slot in the rear panel. A clockwise adjustment provides more gain.